

FUNCTIONALITATI^o

SUPERIATE

MVAC

Audio-HVAC Display Module Function Chart

NOTE: If a unit is marked "o" or circuit board is removed, the corresponding function described in the left side column is not applicable.

Remove Part			UNIT			PRINTED CIRCUIT BOARD		
Important Function			Audio Unit	Display Unit	Climate Control Unit	Front Printed Circuit Board	A/C Switch Printed Circuit Board	Rotary Switch Printed Circuit Board
Audio/Navigation	Controls	Power Switch	o	_____	_____	o	_____	_____
		Volume Control	o	_____	_____	o	_____	_____
		Tone Control	o	_____	_____	o	_____	_____
		Switch Knob Lighting	o	_____	o	o	o	o
		Anti-theft	o	_____	_____	o	_____	_____
		Audio Mode Change	o	_____	_____	o	_____	_____
		Navigation Voice Interruption	o	_____	_____	_____	_____	_____
		Remote Control from Steering	o	_____	_____	_____	_____	_____
		Clock Functions	o	_____	_____	_____	_____	_____
	Radio	Preset	o	_____	_____	o	_____	_____
		Auto Select	o	_____	_____	o	_____	_____
		Tune/Seek	o	_____	_____	o	_____	_____
		Scan	o	_____	_____	o	_____	_____
	CD	Play/Repeat	o	_____	_____	o	_____	_____
		Skip up/down	o	_____	_____	o	_____	_____
Loading/Eject		o	_____	_____	o	_____	_____	
A/C	A/C Control	Auto A/C	_____	_____	o	_____	o	_____
		Temperature Control	_____	_____	o	_____	o	_____
		Draft Control	_____	o	o	o	_____	_____
		Dual A/C	_____	_____	o	_____	o	_____
		Def/Rear Def	_____	_____	o	_____	o	_____
		Mode Change	_____	o	o	o	_____	_____
Display	Main Display	Joy play/Zoom	_____	o	_____	o	_____	_____
		Cancel key/Map Change	_____	o	_____	o	_____	_____
		Menu call	_____	o	_____	o	_____	_____
		Set up View Call	_____	o	_____	o	_____	_____
		Infore View Call	_____	o	_____	o	_____	_____
		Audio View Call	o	o	_____	o	_____	_____
		A/C View Call	_____	o	o	o	_____	_____
	Subdisplay	Show Subdisplay	o	_____	_____	o	_____	_____